

PUCEM TF

Packaging:

4 components

Component A: 2,5 kg Resin

Component B: 2,7 kg Hardener

Component C: 13 kg Filler

Component D: 0,3 kg Pigment Paste

Total set: 18,5 kg

Properties:

- High Chemical resistance
- Flexural Strength > 18 N/mm²
- Compressive Strength > 50 N/mm²
- Temperature resistant
- Slip resistance R 11
- Abrasion resistance

Explanation:

PUCEM TF is an aromatic four component, solvent-free, pigmented, screed floor based on a polyurethane cement. PUCEM TF is known for its great chemical resistance and mechanical strength and is a robust, wear-resistant floor with a long lifespan with an anti-skid finish.

An Eurostep PUCEM TF floor is liquid-tight, making it the ideal floor finish for the food , chemical and the pharmaceutical industry. It excels in chemical resistance against many types of acids, alkalis, salts and solvents, but also against mineral oils, kerosene, petrol, diesel and brake fluids.


Furthermore it also features an extreme heat resistance so it is resistant to thermal shock and thus can withstand hot water. Last but not least the PUCEM TF is characterized by the fast build-up of high strength on a period of short time and still shows an excellent flow and is easy to use.

Applications:

- Food industry
- Chemical industry
- Pharmaceutical industry
- Dairy industry
- Company Kitchen
- Bottling lines


Flexural Strength:

Flex Test



Compressive Strength:


Graph 1



Colors:




Light grey




Grey



Dark grey




Light yellow



Yellow



Green



Blue



Red

Consumption

Screed floor system	Product	Consumption
Wearing Course	PUCEM TF	6 – 6,5 kg/m ²
Broadcast	SL-Quartz 0,4 – 0,8	~ 4 kg/m ²
	SL-Quartz 0,8 – 1,2	~ 4 kg/m ²
Topcoat	PUCEM L	~ 0,7 kg/m ² for 0,4 - 0,8 mm ~ 1,2 kg/m ² for 0,8-1,2 mm

Usage:

PAY ATTENTION!

- Please check if you have the right A and B components.
 - Mixing is very important.
- Use the mixing time strictly because otherwise no chemical reaction takes place.
- When applying the product please wear protective clothing and gloves.

1. Pour the A-Component into a bucket and add the pigment paste (component D).
2. Then add the complete contents of component B to component A.
3. Mix shortly homogeneous with a Collomix DLX 120 HF/DLX 120 M mixing paddle.
4. Add the filler and mix at full power thoroughly until a lump-free mixture for approximately 1 - 2 minutes.
5. Pour out the mixture and spread the material evenly throughout the room and let it flow for about 10 minutes before the start of the broadcast. Always pour the complete contents of the bucket in 1 go to avoid a fast reaction of material left in the bucket. Use a spiked roller if necessary.
For even consumption in a large room it is recommended that the space is divided into planes or strips with pieces of tape. That way you can better regulate consumption.
6. Depending on desired anti-skid level broadcast with 0,4 - 0,8 mm or 0,8 – 1,2 mm quartz.
7. When the entire substrate is coated evenly, the floor needs to cure for approximately 24 hours before it can be walked on. Of course, first test whether the floor is actually is walkable!
8. Now the topcoat PUCEM L can be applied.

Substrate:

The substrate must be sound and sufficiently compression-resistant (at least 25 N/mm²), with a minimum adhesive strength of 1.5 N/mm².

The substrate must be clean and dry and free of dirt, oil, grease and other soiling.

Concrete substrates must be prepared mechanically using abrasive blast cleaning or scarifying equipment to remove cement laitance and achieve an open textured surface.

Weak concrete and loose cementitious levelling must be removed and surface damage such as blowholes and voids must be repaired.

All dust, loose and friable material must be fully removed from all surfaces before the product is applied, preferably using a brush and/or industrial vacuum cleaner.

Remarks:

Do not use PUCEM TF on surfaces with rising damp.

After application Quartzline PUCEM TF must be protected from damp, condensation and water for at least 24 hours (+20 °C).

Non-hardened material reacts with water (foaming), so while working, prevent drops of sweat falling into the material by using a headband and wristband!

Uneven or dirt covered substrates should not be treated with thin coatings. Both substrate and adjacent areas should always be thoroughly prepared and cleaned prior to application.

The incorrect assessment and treatment of cracks may lead to a reduced service life and recurrent cracking.

Immediately process all mixed material, otherwise at the end of the processing time the flow and de-aeration will decrease.

Use material with the same batch numbers to be sure of an exact and even color match.

If heating is required do not use gas, oil, paraffin or other fossil fuel heaters as they produce large quantities of both CO₂ and water vapour which may adversely affect the finish.